

# ROTOR TAIL [H0429-5]



Please read this user manual carefully, it contains instructions for the correct assembly of the model. Please refer to the website www.goblin-helicopter.com for updates and other important information. Thanks You.







#### **RECOMMENDATIONS**

- \* These parts should be used only with models SAB Goblin 630, 700, 770, Urukay, Speed.
- \* Please follow all the instructions shouwn in the Goblin main manual. In this manual please read Chapter 2, Important notes.
- \* Use Loctite on all threads.
- \* Prior to use, lubricate all movements with sprat lubricant.
- \* Possible to use with the follow Tail blades:

3BW5105: SAB blades for 3 blades tail rotor 105 mm

3BW5115: SAB blades for 3 blades tail rotor 115 mm

### **SPARE PARTS**

#### **Aluminum Tail Blade Grip** [H0327-S]



- 4 x Bearing Ø5xØ10x4mm.
- 2 x Thrust bearing Ø5xØ10x4mm.
- 2 x Washer Ø7.5xØ10x0,5mm.

# **Bell Crank Lever** [H0406-S]



- 2 x Tail Pin.
- 1 x Uniball M2.
- 1 x Uniball Spacer.
- 1 x Bell Crank Lever.
- 2 x Flanged Bearing  $\emptyset$  3x  $\emptyset$  7x3mm.
- 1 x Socket Head Cap Screws M3x22mm.
- 1 x Socket Head Cap Screws M2x8mm.
- 1 x Washer  $\emptyset$  3x  $\emptyset$  4x0.5mm. - 1 x Spacer  $\emptyset$  3x  $\emptyset$  4 x 9.6mm.

## **Tail Shaft**





**Tail Pitch Slider** 

- 1 x Tail Pitch Slider 01.

- 1 x Tail Pitch Slider 02.

- 1 x Tail Pitch Slider 03.

- 1 x Spacer 8x 9x3.2mm.

[H0409-S]



- 2 x Flanged Bearings Ø8x Ø12x3.5mm

- 3 x Pin M2.
- 3 x Spacer Ø 2x Ø 3x3mm.
- 3 x Tail Pitch Slider Link.
- 6 x Socket Head Cap Screws M2x6mm.



- 1 x Tail Hub.
- 1 x Set Screw M4x6mm.
- 3 x Socket Head Cap Screws M3x8mm.
- 3 x Washer Ø3xØ7x1mm.
- 3 x Washer Ø5xØ7x0,2mm.





- 1 x Tail Shaft.
- 2 x Set Screws M4x6mm.